

NOTEBOOK COMPUTER SKIN REFERENCE GUIDE

Thank you for purchasing this MANHATTAN® Notebook Computer Skin. These high-resolution, limited-edition designs are printed on durable polypropylene material that's easily applied — and removed without any remaining residue — to help protect new computers from minor everyday hazards and refresh the look of those with minor scratches and abrasions.

DESIGNS AVAILABLE:

Racing Car, Model 475686
Guitar, Model 475679
Flame, Model 475655


Soccer, Model 475662
Earth, Model 475693
Retro, Model 475723
Cityscape, Model 475716



Shown: Streetscape,
Model 475709,
with grid




1. Clean your notebook cover, letting the surface dry before applying the skin.



2. With the skin's grid (back) side facing up and using the notebook cover dimensions, trim the skin to fit. **TIP:** Some notebook covers feature beveled edges, rounded corners or other design characteristics that may affect full adhesion and a flat, secure installation. To compensate, consider trimming up to 2 cm (0.75 in.) more when preparing the skin for application.



3. Place the skin on the notebook cover to confirm that no additional trimming is needed, then peel away the back of the skin to expose the adhesive surface.



4. Carefully position the skin on your notebook cover — taking into account any edge features addressed above in Step 2 — and press it into place.

SPECIFICATIONS • Material: polypropylene • Dimensions: 250 x 375 mm (9.8 x 14.7 in.) • Weight: 62 g (2.2 oz.)


MANHATTANTM
BRINGING COMPUTERS TO LIFE

MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories.

Ask your local computer dealer for more information or visit us online at

www.manhattan-products.com

Copyright © MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.